

6013

AFN
acessórios 4x4



Checklist / Manual de Montagem - Hard-top
porta horizontal
c/ vidro - Alumínio - Land Rover Def. 130



Checklist / Fitting Instructions - Hard-top for
work purposes



Despiezas / Instrucciones de montaje -



0



x


1 x1

47000183




6 x4

45000116



7 x7

45000043



8 x4

45000117



Land Rover Defender
130 Cab. Dupla
TDI/TD5 (94-07)



9 x4

45000052




10 x7

45000074



11 x14

45000050



13 x3

45000118



Fêmea de Cravar M6

☐ Fêmea Freitada M6

☐ Anilha M6x15x1,6

☐ Anilha fioM6x7x20

14 x1

45000523



15 x1

45000522




16 x2

47000553



17 x4

45000008




☐

☐

☐ Prf. Cb. Sx. M8x30


18 x4

45000011



19 x5m

45000492



Anilha aba larga M8

☐ Esp.Ades. Iso.p/ HT.

☐



1



2



3



4



5



6



7



8

