



WILDBEAR

Fitting Instructions BA 7557

From  **Bearthmach**
LAND ROVER PARTS

-2" Lowered Rear Top Shock Mounts Defender, Discovery 1, Range Rover Classic

KIT CONTENTS

2 x -2" Shock Mounts
6 x M10 x 110mm bolts
6 x M10 washers
6 x M10 lock nuts

When working on your vehicle please ensure that it is adequately chocked, and where applicable supported on axle stands.

If in doubt please refer to a qualified technician or your nearest Wildbear™ fitting centre.

INSTRUCTIONS

- Engage 2nd gear and apply hand brake.
- Slacken rear wheel nuts, jack the vehicle and support the rear axle with axle stands.
- Remove the rear wheels.
- Slacken and unscrew the nut on the top shock upper mount and free the shock absorber from the pin making careful note of the correct sequence of bushes and washers. (fig 1)
- Undo the three bolts holding the original top shock mount to the chassis and discard part and bolts.
- Utilising the three of the M10 x 110mm bolt sets supplied install the Wildbear™ -2" shock mount using the original holes in the chassis (Fig 2)
- Install the shock back on to -2" shock mount ensuring the bushes and washers are assembled in the correct sequence.
- Check all bolts are properly tightened.
- Repeat for opposite side of vehicle.
- Refit rear wheels with wheel nuts and remove vehicle from axle stands.
- Fully tighten and correctly torque wheel nuts.



Fig 1



Fig 2

*Thank you for buying and using Wildbear™ Products.
Proudly Designed and Manufactured in the UK*



Est. UK 1958

Bearthmach
LAND ROVER PARTS

Parts and Accessories for all Land Rovers



Head office: Bearmach Limited, Bearmach House, Unit 8, Pantglas Industrial Estate, Bedwas, Caerphilly, CF83 8GE
Tel: +44 (0)29 20 856550 Fax: +44 (0)29 20 865586 Email: bearmach@bearmach.com Web: www.bearthmach.com