



WILDBEAR

Fitting Instructions
BA 7582 / BA 7583*
Tank Guard
Defender 90 Tdi

From



Est. UK 1958
Bearthmach
LAND ROVER PARTS

KIT CONTENTS

1 x Guard
3 x Brackets
6 x M10x30 Sets

10 x M10 Washers
4 x M10 Nylocs

TOOLS REQUIRED

17mm Socket
Ratchet
17mm Spanner

When working on your vehicle please ensure that it is adequately chocked, and where applicable supported on axle stands.

If in doubt please refer to a qualified technician or your nearest Wildbear™ fitting centre.

**We recommend wiping the alloy surface with a soft cloth and WD40 to remove protective film used in manufacture.*

INSTRUCTIONS

- This guard fits directly under the tank, it is held in place by the brackets supplied in the kit.
- Mount the brackets to the corresponding holes in the vehicle chassis and outriggers.
- When these have been fitted in to place the guard can then be mounted to the brackets in the designated position.
- All bolts must then be tightened fully and checked.

Thank you for buying and using Wildbear™ Products.

Proudly Designed and Manufactured in the UK



Est. UK 1958

Bearthmach
LAND ROVER PARTS

Parts and Accessories for all Land Rovers



Head office: Bearmach Limited, Bearmach House, Unit 8, Pantglas Industrial Estate, Bedwas, Caerphilly, CF83 8GE
Tel: +44 (0)29 20 856550 Fax: +44 (0)29 20 865586 Email: bearmach@bearmach.com Web: www.bearthmach.com