



WILDBEAR

Fitting Instructions

BA 7596 / BA 7597* / BA 7598 / BA 7599*

Transmission Guard

Discovery 2 Td5 / V8

From



Est. UK 1958
Bearthmach
LAND ROVER PARTS

KIT CONTENTS

1 x Transmission Guard	6 x M8 Rivet nuts
6 x M8x30 Sets	
6 x M8 Washers	

TOOLS REQUIRED

13mm Socket	Drill and bit
Ratchet	Felt tip pen
13mm Spanner	
Rivet Nut Tool	

INSTRUCTIONS

- This guard mounts directly under the transmission using the two crossmembers. (One to the front and one to the rear of the transmission. The curve of the guard will logically dictate its position on the cross members.
- It may be necessary to have assistance in supporting the guard to allow the position of the mounting holes to be marked on the crossmembers. Ensure it is held in a central position (left and right).
- After the holes have been marked, drill the holes and fix the rivet nuts into position.
- The guard can then be mounted using the bolts and washers provided. Tighten and check all bolts after fitting.

When working on your vehicle please ensure that it is adequately chocked, and where applicable supported on axle stands.

If in doubt please refer to a qualified technician or your nearest Wildbear™ fitting centre.

**We recommend wiping the alloy surface with a soft cloth and WD40 to remove protective film used in manufacture.*

Thank you for buying and using Wildbear™ Products.

Proudly Designed and Manufactured in the UK



Est. UK 1958

Bearthmach
LAND ROVER PARTS

Parts and Accessories for all Land Rovers



Head office: Bearmach Limited, Bearmach House, Unit 8, Pantglas Industrial Estate, Bedwas, Caerphilly, CF83 8GE
Tel: +44 (0)29 20 856550 Fax: +44 (0)29 20 865586 Email: bearmach@bearmach.com Web: www.bearthmach.com