



B WILDBEAR



Fitting Instructions BA 7603 Universal Diff guard fitting instructions

This product is only suitable for Land Rover vehicles with Defender or Discovery 2 style axles

1. Park the vehicle on level ground and chock the road wheels.
2. Remove the track rod catcher (Defender models) or steering damper bracket (Range Rover and Discovery models) from the underside of the differential.
3. Fit the main diff guard to the axle and bolt up in to place using the bolts supplied.
4. Disconnect the battery and alternator and tack weld the two upper locating lugs to the diff casing whilst still fitted to the diff guard.
5. Remove the diff guard and fully weld the lugs to the axle casing.
6. Refit the diff guard and fit the two securing bolts through in to the top two lug.
7. Tighten all the bolts firmly
8. Refit the steering damper to the base of the diff guard in the case of the Range Rover and Discovery models.
9. Reconnect the battery and alternator



**Est. UK 1958
Bearthmach**
LAND ROVER PARTS

Parts and Accessories for all Land Rovers



Head office: Bearmach Limited, Bearmach House, Unit 8, Pantglas Industrial Estate, Bedwas, Caerphilly, CF83 8GE
Tel: +44 (0)29 20 856550 Fax: +44 (0)29 20 865586 Email: [bearmach@bearmach.com](mailto:bearthmach@bearmach.com) Web: www.bearthmach.com