

Fit the top shock mounts



If you are using the hydraulic bump stops and fitting to a full bodied vehicle follow the next steps.

Mark the tub so that the bump stop will clear, to give radiused corners use a small hole cutter/saw to radius each corner. (Remember, measure twice cut once)



Use an air hack saw or jig saw to cut between the holes

