



Sit the bump stop mount in place and ensure that it clears the body work



When lining up the rear bump mounts, the chamfer on the relocation cone faces inwards to the centre of the vehicle and the centre of the bump stop tube is off set rearwards, the webs with the two holes always face forwards and outwards. The chamfer is not shown in this picture

