

Once you have lined up the mount, mark and drill one hole, once this is done bolt the heavy duty retaining ring in place and use this as a template to drill the remainder of the holes, ensuring that the ring is set out with the holes in the correct position to match the mount



Bolt the mount into place



Grease the bump stop with copper ease and fit

