



Fit the rear shocks; ensure that the thinner of the two rubbers is on the inner side of the mount then refit the springs using the retainers provided



Mount the reservoir. (mounts are available separately)
DO NOT over tighten and mount using the ends of the reservoirs.