

Fit the covers



Remove the front springs and shocks, offer up the front turrets and mark the areas that need to be removed/panel beat



NOTE: up to the Puma the inner wings are steel and therefore some of the re working can be carried out with panel beating, the Puma has plastic inner wheel arches and therefore there is more cutting involved.

Remove the unwanted areas of the inner wing

