

You will need to add a tear drop to the hole in the top of the inner wing



Mount the turret using the 4 original holes, using the HD mounting ring as a template drill the remaining holes ensuring that the ring is aligned with the turret holes



Fit the relocation cone

