

Fit the front turret support bracket to the steering box holes and then drill the holes in the front turret using an 8mm drill bit



Fit the springs and fit the lower shock mounts



Fit the bump stop striker plates to using the radius arm bolts

