

Fit the bump stop and front shock



Mount the reservoirs



NOTE: On the Puma you will need to move the air box mounts.

IMPORTANT: Once re assembled check that the bump stop prevents upwards travel of the rear axle prior to the spring becoming coil bound or the shock bottoming out and also check that it also prevents the axle striking the relocation cone, on the front ensure that the bump stop stops the axle before the shock bottoms out.