



MULTI-FIT CARGO MAT

PRODUCT INFORMATION SHEET

"Adds much needed, non-skid tray protection to your ute"



SPECIFICATIONS

Materials	Heavy duty solid rubber construction
Capacity	Not applicable
Weight	20–30kg
Warranty	5 Year No-Fuss Warranty

VEHICLE APPLICATIONS

Part No 44X01 – Suits all Japanese Dual Cab Utes

PRODUCT TIPS

- Read fitting instructions first and remember you can always trim more off, but you can't add it back on
- Use several cutting strokes along your chosen line, rather than attempting to cut right through the mat on your first cut
- Always remove the mat from your ute after rain or washing to allow water to drain away or evaporate – reinstall when fully dry

SAFETY PRECAUTIONS

- When cutting observe safety precautions and keep fingers away from cutting blade

...Continued over page

AUGUST 2006

Kingsley Enterprises Pty. Ltd.
Phone: 1800 654 767
sales@kingsleyenterprises.com.au
www.bushranger.com.au

9 - MULTI-FIT CARGO MAT
PRODUCT INFORMATION



MULTI-FIT CARGO MAT

PRODUCT INFORMATION SHEET

"Adds much needed, non-skid tray protection to your ute"

FEATURES	BENEFITS
Oversized Multi-Fit design has moulded-in trim lines so the mat can be easily trimmed down to suit each individual ute model	Saves you money and allows you to individually trim the mat to suit your exact needs.
5mm thick solid construction	Will not crack, tear or warp
Prevents damage to ute cargo area	Will save you \$\$\$ in resale value of your ute
Simple to follow DIY instructions included	See instructions overleaf
Reduces load shift	Helps insulate and deaden sound to reduce hollow road noise
Flat surface with ribs	Allows for easy loading and unloading
Underside dimples	Gives effective grip so the mat does not move and allows for air flow
Easily rolled for quick removal when required for cleaning or storage	

FITTING & CARE INSTRUCTIONS *(Included in Product Packaging)*

Tools Required: A sharp, snap-off-blade knife or similar.

The multi-fit mat is designed to be easily trimmed to your own vehicle and will therefore be oversized in some areas.

- Step 1. Lay the mat out in your Ute and align the rear edge of the mat with the rear of the Ute tray, with the tailgate closed. You can then judge where you want to trim the mat, either around the wheel arches, in it's overall width, in it's width between the wheel arches, or in it's length.
- Step 2. Press the mat down with your fingers and select the moulded-in trimming guideline, which is closest to the shape you require.

NOTE: You can use either side of the moulded-in trim guide lines as your cutting line but do not cut away too much to start with as you can always cut more away later, but you can't add it back on.

It is recommended you remove the mat from the ute before cutting and lay it out flat on a suitable surface. This will avoid any risk of scratching the vehicle's paintwork and will give you more control over the knife when cutting.

- Step 3. Cutting is easy using a snap-off-blade knife (or similar). Make several cutting strokes along the line to cut through rather than make a single heavy stroke.

CAUTION: Take all necessary safety precautions and ensure fingers are well out of the way of the knife.

IMPORTANT:

Your Mat should be removed from your ute after rain or washing to allow both the ute and the mat to fully dry before re-installing.