



#B WILDBEAR



Fitting Instructions BA 7604/BA 7605 Rockslider

This product is only suitable for Land Rover vehicles with Defender style axles. It may not be possible to fit the Rockslider to vehicles with rubber drive couplings. If in doubt check the clearance around the drive joint at the diff to the Rockslider by jacking up one road wheel rotating the prop shaft to ensure the coupling does not touch the Rockslider.

NOTE. Classic Range Rovers and Discovery 1 the Rockslider is now fitted with two top mounted holes.

When fitting the Rockslider to the above vehicles use the inner most top hole by pushing the guard in toward the diff pan. This must be done on these vehicles to ensure adequate clearance of the fuel tank bracket and fuel tank.

Failure to do this may result in fuel tank damage! Or the guard fouling the fuel tank bracket on Range Rover and Discovery.

NOTE: For 300TDI Discovery models some vehicles were fitted with a rubber drive flange at the rear differential. Our BA 7605 has a spacer plate and longer bolts for this application in order for the guard to clear the drive flange.

1. Park the vehicle on level ground and chock the road wheels.
2. Remove the top two differential flange securing nuts and gently pull the brake pipe bracket off the two studs (take care not to damage the brake pipes).
3. Fit the Rockslider to the axle and bolt up in to place using the bolts supplied. At this stage only lightly tighten these bolts to allow for adjustment.
4. Fit the top bracket to the two studs at the top of the differential flange with the long lug facing over the top of the casing refit the brake pipe bracket and refit the nuts. (note the fitting of washers under the bracket to pull the guard as close as possible to the diff pan as detailed above)
5. Fit the securing bolt supplied through the lughole.
6. Using a pair of mole grips clamp the two brackets together so that they pull up tight to each other the bolt through the top bracket hole and tighten.
7. Tighten the bolt firmly
8. Tighten all other bolts and nuts firmly including the top diff bolts
9. Check that the brake pipes do not rub on any of the components. Gently bend the pipes away from any of the parts so they do not rub



Bearmach
LAND ROVER PARTS

Parts and Accessories for all Land Rovers



Head office: Bearmach Limited, Bearmach House, Unit 8, Pantglas Industrial Estate, Bedwas, Caerphilly, CF83 8GE
Tel: +44 (0)29 20 856550 Fax: +44 (0)29 20 865586 Email: bearmach@bearmach.com Web: www.bearmach.com