



WILDBEAR

***Fitting Instructions
BA 7645
Lamp Pod - Non Air Con***

From



Bearthmach
LAND ROVER PARTS

When working on your vehicle please ensure that it is adequately chocked, and where applicable supported on axle stands.

If in doubt please refer to a qualified technician or your nearest Wildbear™ fitting centre.

INSTRUCTIONS

1. Using the single bolt fixing through the pre-drilled hole. Remove the nylock nut and one of the washers, using the remaining as spacers so the when in position the lamp unit is in the centre of the hole. When happy with the position refit the washer, nut and tighten.
2. Position the pod on to the front of the vehicle bonnet so that the front face of the light pod is vertical in relation to the floor. Move the pod forward or back to achieve this.
3. Ensure that the pod is central from left to right on the bonnet.
4. With the aid of an assistant press the pod firmly on to the bonnet to as the compress the edging strip and check items 1 and 2 above are still correct.
5. Still with the pod pressed firmly on to the bonnet drill two 8.5mm holes through the pod at the rear edge allowing for the size of the washer to the edging trim. Space the holes as far apart as possible. Prior to drilling confirm that it is clear to drill through the bonnet over the engine and also that the holes will miss the stiffening ribs under the bonnet shell where applicable.
6. Use tow of the stainless steel fixing screws to secure the pod in place using the holes drilled.
7. Choose a suitable location for the front fixing holes as far forward on the sides of the pod as possible. This will eliminate any bounce between the pod and the bonnet. It is possible to tuck the fixing washers under the edging trim to allow the holes to be drilled as far forward as possible. Once again prior to drilling the two 8.5mm holes confirm the location of the holes on the underside of the bonnet. It is particularly important to check this on Defender bonnets as access to the holes can be difficult.
8. Once the holes have been drilled secure the front of the pod using the other stainless steel fixing screws supplied.
9. Adjust and tighten the spot lamp mounting bolts to suit the spot lamp aim.

Thank you for buying and using Wildbear™ Products.

Proudly Designed and Manufactured in the UK



Est. UK 1958

Bearthmach
LAND ROVER PARTS

Parts and Accessories for all Land Rovers



Head office: Bearmach Limited, Bearmach House, Unit 8, Pantglas Industrial Estate, Bedwas, Caerphilly, CF83 8GE
Tel: +44 (0)29 20 856550 Fax: +44 (0)29 20 865586 Email: bearthmach@bearthmach.com Web: www.bearthmach.com